


1


DE | NICHT ENTHALTEN SE | ÎNGĂR EȚI
EN | NOT INCLUDED CZ | NENÍ V CENĚ
FR | NON INCLUS SK | NEZAHŔŇA
IT | NON INCLUSO RO | NU ESTE INCLUS
NL | NIET INBEGREPEN PL | NIE ZAWARTY




D
i
DE | NICHT ENTHALTEN
EN | NOT INCLUDED
FR | NON INCLUS
IT | NON INCLUSO
NL | NIET INBEGREPEN
SE | ÎNGĂR EȚI
CZ | NENÍ V CENĚ
SK | NEZAHŔŇA
RO | NU ESTE INCLUS
PL | NIE ZAWARTY




2




3







4



5





DE | Installationsanleitung SE | Installationsanvisning
 EN | Installation Manual CZ | Návod k instalaci
 FR | Notice d'installation SK | Návod na inštaláciu
 IT | Manuale d'installazione RO | Instrucțiuni de instalare
 NL | Installatiehandleiding PL | Instrukcja montażu

Art.-Nr. 10581576
 Manufactured for
 HORNBACH Baumarkt AG
 Hornbachstraße 11
 76879 Bornheim / Germany
 www.hornbach.com

DE | BEVOR ES LOSGEHT SE | INNAN DU STARTAR
 EN | BEFORE STARTING CZ | PŘED ZAČÁTKEM
 FR | AVANT DE COMMENCER SK | PRED ŠTARTOM
 IT | PRIMA DI INIZIARE RO | ÎNAINTE DE A ÎNCEPE
 NL | VOOR HET STARTEN PL | PRZED ROZPOCZĘCIEM

